Computer Networks

PAK AUSTRIA FACHHOCHSCHULE: INSTITUTE OF APPLIED SCIENCES AND TECHNOLOGY DEPARTMENT OF ELECTRICAL AND COMPUTER ENGINEEING

Computer Networks COMP-352L LAB MANUAL 6



School of Computing Sciences

Prepared by:

Sir Shais Saleem

Ms. Laiba Sohail

Domain Name Server configuration

Overview:


What is DNS?

The Domain Name System (DNS) is a hierarchical and decentralized naming system used to translate human-readable domain names (like www.example.com) into machine-readable IP addresses (like 192.0.2.1). This translation is essential because, while humans prefer to remember names, computers and network devices communicate using numerical IP addresses.


Steps:

Following are the steps to configure email server:


- 1. Create a topology like given below having following devices:
 - a. 2 PC's
 - b. A switch
 - c. A server




- 2. Now create connects between the devices as:
 - i. Connect both PC's to the switch using straight through cable.
 - ii. Connect switch to server through straight through cable.



- 3. Now start with configuring server, assign the IP addresses to server.
 - i. Click on Server, go to Config
 - ii. Assign IP address to DNS server and close server configuration.




- iii. Again, click on Server and go to Desktop
- iv. Then click on IP Configuration and assign IP address




- v. Now go to Services and click on DNS from left bar.
- vi. Give Name and Address here as:

Name:worldwideweb.com

Address:192.168.10.0



vii. Click on ADD




viii. Now assign IP addresses to PC's

a. Click on PC0 and go to Desktop, click on IP configuration

PC0:

IP Address: 192.168.10.2 Subnet Mask: 255.255.255.0 DNS Server: 192.168.10.1



ix. Repeat the steps for PC1 and PC2 as well

a. PC1:

IP Address: 192.168.10.3 Subnet Mask: 255.255.255.0


DNS: 192.168.10.1

b. PC2:


IP Address: 192.168.10.4 Subnet Mask: 255.255.255.0

DNS: 192.168.10.1


x. Now pass the message packet from Server to all three PC's and check the connection is established or not.



xi. Go to Simulation mode and see the packet transferring.



xii. Show the packets transferring from server to PC's through switch.



xiii. This is how DNS configuration actually happens.

LAB TASK:

1. Do the same configuration using 5 PC's and make a report of it showing each step.